

LANSSCIH10

Installation Instructions

Lankota GENERATION II Stalk Stomper® Mounting Kit for CaseIH® 1000 Series Corn Heads
2-Row Coverage

LANKOTA®

270 West Park Avenue

Huron, SD 57350

866-526-5682

Numerical Parts List

Part Numbers	Description	Quantity
LANSSCIH10C	Top Toolbar Bracket	2
LANSSCIH10D	Adjustable Bottom Toolbar Bracket	2
LANSS659-B	Adjustable Mount Tube	2
REDB712	5/8"-11 x 3.0" Bolt	2
REDKRJF	5/8" Top Lock Nut	2
LANB514	1/2"-13 x 3.5" Bolt	2
LAN3722	1/2"-13 Serrated Lock Nut	10
LANSS704	Custom Hitch Pin	2
LANFB528	1/2"-13 x 7.0" Bolt	4
LANFK528	1/2"-13 x 7.0" Carriage Bolt	4
Optional Part List		
LANSS601A-POLY	Poly skid shoe	1 per row
LANSS601A-POLYBH	8 carriage bolts and flange nuts per bag	1 per row

Pictorial Parts List

				
LANSSCIH10C (2)	LANSSCIH10D (2)	LANSS659-B (2)	REDB712 (2)	REDKRJF (2)
				
LANB514 (2)	LAN3722 (10)	LANSS704 (2)	LANFB528 (4)	LANFK528 (4)

		
LANSS601A-POLY	3/8" x 1" Carriage Bolt (8 per shoe)	3/8" Flange Lock Nut (8 per shoe)

Stalk Stomper Disclaimer

1. Attach desired header to the combine. Lock the head to the combine.
2. Raise the head off the ground and lower the safety stop on the feeder house cylinder.
3. Set the parking brake on the combine.
4. Turn off the combine engine and remove the key.

Preparation

Stalk Stomper Disclaimer

The most effective use of the Lankota Stalk Stomper® is achieved by adjusting the stomper pad so that when the corn head is at its normal cutting height, the pad of the shoe is 1" above the ground. Over compression of the spring can shorten the life of the stomper spring and may result in undue damage NOT covered by Lankota's Limited Warranty.

Installation

Refer to Figure 1.1

1. Insert the 2 carriage bolts into the square holes in the LANSSCIH10C mount and slide it under the gearbox from the back side.

Hardware:

LANFK528

1/2" X 7" Carriage Bolt



Figure 1.1

Refer to Figure 1.2

2. Install the LANSSCIH10D mount underneath the row unit with the mount tube pointing towards the back of the head. Insert 1/2" bolts and lock nuts

Hardware:

LANFB528

1/2" X 7" Bolt

LAN3722

1/2" Serrated Flange Nut

3. Tighten all hardware.



Figure 1.2

Optional Stalk Stomper® Poly Installation

Refer to Figure 1.3

Note: If you did not order the optional poly please skip to step 1.8 on page 9.

4. Attach poly wear plates to bottom of the Lankota Stalk Stomper® shoe utilizing 8 bolts and 8 nuts provided in the LANSS601A-POLYBH bag of hardware.



Figure 1.3

Refer to Figure 1.4

5. Slide the Stalk Stomper onto the 1.5" square tube and secure using the LANSS704 Hitch pin.



Figure 1.4



For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682