

# **LAN204828BLKS**

## **Installation Instructions**

**Lankota Mount Bracket for Multi-Coupler**

# **LANKOTA®**

**270 West Park Avenue  
Huron, SD 57350  
866-526-5682**

# Numerical Parts List

<b>Part Numbers</b>	<b>Description</b>	<b>Qty</b>
LAN204828BLK	Black Bracket	1
LAN18A	3/8"-16 x 1.0" Carriage Bolt	4
LAN3718	3/8"-16 Serrated Flange Nut	4

# Pictorial Parts List



# Kit Installation

## Refer to Figures 1 & 2

1. On the left side of the feeder house opening locate a spot 24" from the feeder house opening and 12" down from the top main beam and center the storage bracket in that spot (Figure 1).
2. Place multi coupler block in the storage bracket to make sure that there is enough hose to reach the mounting location.
3. Mark and drill the four holes using the storage bracket and template. Secure storage bracket with four carriage bolts (LAN18A) and four lock nuts (LAN3718).

**For further technical assistance,**

**Call Lankota Inc. at:**

**1-866-526-5682**

**Figure 1**



**Figure 2**

