

LAN501

Installation Instructions

1-3/8" Sprocket to Spline Adapter

DO NOT USE with chopping corn heads or platform heads equipped with air reel systems.

LANKOTA[®]

270 West Park Avenue

Huron, SD 57350

877-860-7669

Numerical Parts List

<i>Part Numbers</i>	<i>Description</i>	<i>Quantity</i>
LAN101A	Backing Ring for 21 Spline Sprocket Adapter	1
LAN501B	Sprocket Drive to Male 1-3/8" 540	1
LAN3722*	Serrated Flanged Lock Nut	4
LAN22A32*	½" – 13 x 1.50" HHCS Bolt	4

**included in bag of hardware.*

Pictorial Parts List

			
LAN3722 (4)*	LAN22A32 (4)*	LAN501B (1)	LAN101A

1. Procedure

Refer to Figure 1.1 & 1.2

1.1 Install the four Bolts (LAN22A32*) through the four half moon notches on the Backing Plate (LAN101A).

1.2 Slide Adapter (LAN501B) onto the four bolts and secure with nuts (LAN3722*). Depending on the combine model you may be able to put the bolts in from the front. Either way will work.

1.3 Tighten nuts with a $\frac{3}{4}$ " wrench.

Figure 1.1



Figure 1.2



For further technical support, you may contact Lankota Inc: 1-866-526-5682