

# **LAN560**

## **Installation Instructions**

**Dummy plug and mounting plate.**

# **LANKOTA<sup>®</sup>**

**270 West Park Avenue**

**Huron, SD 57350**

**866-526-5682**

# Parts List



LAN166990



LANEC560 & LAN175880

<b>Part Number</b>	<b>Description</b>	<b>Qty</b>
LANEC560	Dummy Plug	1
LAN201300	Blank Multi-coupler Block with Bushings & Shoulder Bolts	1
LAN175880	Snap Ring	1

**Any Further Technical Questions: Call Lankota at 1-866-526-5682**

# Dummy Plate and Plug Installation

This kit allows the operator to maintain routine header functions when connecting a JD® combine with single point to a header with no electrical wiring harness.

*Refer to Figure 1*

1. Slide dowel pins into single point block on the combine and pull down on the handle to lock in place.



*Figure 1*