

LANFRCIH190

Installation Instructions

Lankota CNH Foot Rest for:

CIH Combines - X120 Series, 7010, 8010 & X230 Series (Non- Common Cab)

New Holland Combines - CR90XX Series (except CR9090)

LANKOTA®

**270 West Park Avenue
Huron, SD 57350
866-526-5682**

Numerical Parts List

<u>Part Numbers</u>	<u>Description</u>	<u>Qty</u>
LANFRCIH190W	Foot Rest Weldment	1
LAN14M7298	M8-1.25 Serrated Flange Nut	2

Pictorial Parts List



Kit Installation



Figure 1

1. Turn off the combine engine and remove the key.
- Refer to Figure 1**
2. Mark the center point of the floor mat in front of the steering column.
 3. Lift the boot from around the steering column.
 4. Cut the floor mat along the marked point and pull the spliced ends around the column.

Refer to Figures 2 & 3

5. Using a razor blade, cut off the excess caulking so it is flush with the steel frame.
6. Clean the floor of any dirt and debris.
7. Remove the front 2 nuts from the steering column and discard.

Note: Leave the washers in place.



Figure 2



Figure 3

Kit Installation

Refer to Figures 4 & 5

8. Place the foot rest on the washers and the steel cab frame with the Lankota Sticker facing out the windshield.
9. Fasten the weldment in place with the M8 flange nuts (LAN14M7298) and tighten.



Figure 4



Figure 5

Kit Installation

Refer to Figures 6 & 7

10. Fold the rubber floor mat ends back into place and reseat the steering column boot.
11. If you wish, you can cut out a section of the mat so it will lie flat around the foot rest.

Figure 7



Figure 6

For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682