

LANGD200

Installation Instructions

Flex Head Grain Divider Point for 900 & 600 Series Flex Heads with Poly Spouts

LANKOTA[®]

270 West Park Avenue
Huron, SD 57350
866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANGD201	Grain Dividers - Single	2

Pictorial Parts List



Preparation

- 1. Attach desired header to the combine. Lock the head to the combine.**
- 2. Raise the head off the ground and lower the safety stop on the feeder house cylinder.**
- 3. Set the parking brake on the combine.**

Kit Installation

Refer to Figures 1 & 2

1. Remove the two indicated screws from the bottom of the factory installed poly divider point. Slide divider out of the snoot tube.
2. Slide a grain divider (LANGD200) into the tube and line up the larger of the holes and reinstall the screw. The small screw will not be reused in this application.
3. Repeat on the other side.



Figure 1



Figure 2

For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682