LANGD400 Installation Instructions

Grain Divider Point for John Deere 600 Series 2016+ HydraFlex & Draper Heads & 2015 Draper Heads

LA N COTA

270 West Park Avenue Huron, SD 57350 866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANGD401	Grain Dividers - Single	2

Pictorial Parts List



Preparation

- 1. Attach desired header to the combine. Lock the head to the combine.
- 2. Raise the head off the ground and lower the safety stop on the feeder house cylinder.
- 3. Set the parking brake on the combine.

Kit Installation

Refer to Figure 1

- 1. Remove the metric screw from the front/top of the factory installed poly divider point and the two bolts from the bottom. Remove the plastic point.
- 2. Remove the two metric screws retaining the green metal plate.
- 3. Put plastic point and metal plate aside or throw away.
- 4. Set a LANGD400 divider on the exposed snout point and replace all hardware in original location and tighten.
- 5. Repeat on the other side.

For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682



Figure 1