

LANSS3408R8

Installation Instructions

Lankota GENERATION II Stalk Stomper® Mounting Kit for CaseIH® 3408 Series Corn Heads

8-Row Coverage


LANKOTA®

**270 West Park Avenue
Huron, SD 57350
866-526-5682**

Numerical Parts List

Part Numbers	Description	Qty
LANSSCIH3400A	Head Toolbar Mount	4
LANSSB111BLK	111" Stalk Stomper® Tool Bar	2
LANSS659	Flip Up Stalk Stomper Mount	8
LANSS3408R8BH	Box Containing Bags of Hardware	1
LANSS400BH	LANSSCIH3400A Bag of Hardware	4
LAN2600UBOLT	U-bolt 5/8" x 4.125" ID x 5.5" length	2
LAN600UBOLT	U-bolt 5/8" x 2.265" ID x 3.75" length	2
LAN690830	5/8" Serrated Flange Nut	8
LANSS668BH	LANSS668 Bag of Hardware	8
LAN600UBOLT	U-bolt 5/8" x 2.265" ID x 3.75" Length	2
LAN690830	5/8" Serrated Flange Nut	4
LANFNHVK	1/2"-13 x 2.5" Flanged Cap Screw	1
LANFNXC1	1/2"-13 Flanged Nyloc Nut	1

Pictorial Parts List

				
LANSSCIH3400A (4)	LANSSB111BLK (2)	LANSS659 (8)	LAN2600UBOLT (8)	LAN600UBOLT (24)
				
LAN690830 (64)	LANFNHVK (8)	LANFNXC1 (8)		

Preparation

1. Attach desired header to the combine. Lock the head to the combine.
2. Raise the head off the ground and lower the safety stop on the feeder house cylinder.
3. Set the parking brake on the combine.
4. Turn off the combine engine and remove the key.

Installation

Refer to Figure 1

1. Remove the shield between rows 2 & 3 by removing the 4 marked carriage bolts. Reinstall and tighten bolts after shield is removed.

Refer to Figure 2

2. Repeat between rows 4 & 5 and 6 & 7.

Figure 1





Figure 2



Refer to Figure 3

3. Install the toolbar mount brackets (LANSSCIH3400A) to the head 4"x4" box tube where the shields were removed. Do not tighten.

Hardware:

LAN690830	5/8" Serrated Flange Nut
LAN2600UBOLT	4" U-bolt

Refer to Figure 4

4. There will be two mount brackets installed at the center of the head between rows 4 & 5.

Note: For best support of the outer 2 rows on each side, make sure outer LANSSCIH3400A mounts are close to the outside of the head. They will need to be up against the row unit for rows 2 & 7.

5. Attach the tube (LANSSB111BLK) to the mounts.

Hardware:

LAN690830	5/8" Serrated Flange Nut
LAN600UBOLT	2.5" U-bolt

Figure 3




Figure 4

Figure 6

Refer to Figure 6

6. Install the LANSS659 row mounts centered in line with each row as shown. Tighten all hardware.

Hardware:

LAN600UBOLT	U-bolt 5/8" x 2.6" x 3.7"
LAN690830	5/8" Serrated Flange Nut

7. Bolt the Stalk Stomper shoe (LANSS651) to the flip up mount (LANSS659). Tighten and secure. Use the flip up option of the flip up mounts to clear tires on trailers.

Hardware

LANFNHVK	1/2" x 2.5" Flanged Bolt
LANFNXC1	1/2" Flanged Nyloc Nut



Figure 7



Stalk Stomper Disclaimer

Stalk Stomper Disclaimer

The most effective use of the Lankota Stalk Stomper® is achieved by adjusting the stomper pad so that when the corn head is at its normal cutting height, the pad of the shoe is 1" above the ground. Over compression of the spring can shorten the life of the stomper spring, increase wear on the poly liner, and may result in undue damage NOT covered by Lankota's Limited Warranty.

For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682

