

LANTB75684

Installation Instructions

Front Weight Bracket Mounted Tool Box for 6R & 7R John Deere Tractors

LANKOTA®

270 West Park Avenue

Huron, SD 57350

866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANTBJD100-A	Tool Box Assembly	1
LANTB756A	Tool Box Mount	2
LANTB756B	Tool Box Mount Stabilizer	1
LANFB832	3/4"-10 X 8" Hex Head Bolt	1
REDWU58	3/4" Flat Washer	2
LANF0DQ0	3/4"-10 Nylon Lock Nut	1
LAN18A	3/8"-16 X 1" Carriage Bolt	4
LANFNW7G	3/8"-16 Flange Nylon Lock Nut	4
LAN506K	1/2"-13 x 1-1/2" Carriage Bolt	4
LAN22000	1/2" Flat Washer	4
LAN1137030	1/2"-13 Nylon Lock Nut	4

Pictorial Parts List

					
LANTBJD100-A (1)	LANTB756A (2)	LANTB756B (1)	LANFB832 (1)	REDWU58 (2)	LANF0DQ0 (1)
					
LAN18A (4)	LANFNW7G (4)	LAN22000 (4)	LAN506K (4)	LAN1137030 (4)	

Installation

Refer to Figure 1

1. Loosely assembly the Tool Box Mounts (LANTB756A) to the front side of the Tool Box Mount Stabilizer (LANTB756B) using the provided 3/8"-16 x 1" Carriage Bolts (LAN18A) and 3/8"-16 Nylon Lock Nuts (LANFNW7G).

Refer to Figures 2

2. Hang the mount assembly on the front weight bracket and secure with the 3/4"-10 x 8" Hex Head Bolt (LANFB832), 3/4" Flat Washers (REDWU58), and 3/4"-10 Nylon Lock Nut (LANF0DQ0). Tighten all hardware.

Figure 1



Figure 2



Installation

Refer to Figure 3

3. Place the Tool Box Assembly (LANTBJD100-A) on top of the mounts and install the 1/2" Flat Washers (LAN22000) and 1/2"-13 Nylon Lock Nuts on the inside of the tool box. Tighten all hardware. Adjust the lid chains if necessary to avoid hitting the grill guard.

Figure 3



For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682