

LANEC200

Installation Instructions

**16 pin on combine to 31 pin header adapter harness. This harness will not allow the use of potentiometer sensors.
6 Pin weather pack is to power Dial-O-Matic™ on an F-Series Head.**

LANKOTA®

270 West Park Avenue

Huron, SD 57350

866-526-5682

Pictorial Parts List

LAN5250905



Any Further Questions, Please Contact Lankota: 866-526-5682