

LANEC302

Installation Instructions

Connect Wiring Harness from Early Model Row Crop heads to Single Point Combine Hook-Up.

(without hydraulic deck plates)

LANKOTA[®]

270 West Park Avenue

Huron, SD 57350

866-526-5682

Numerical Parts List

Part Numbers	Description	Quantity
LAN16690A	Adapter Plate for Electrical Adapter	1
LAN175880	Snap Ring	1
LAN5250906	Electrical Wire Harness	1

Pictorial Parts List



LAN 166990A



LAN175880



LAN 5250906

1. Installation Instructions

Refer to Figure(s) 1.1 & 1.2

1. If header is equipped with the older style 16PIN wiring harness which is comparable to the size of your thumb, connect the male end of Wiring Harness (LANEC100, not sold with kit) to header wiring harness first. Tighten plastic locking collar.
2. Connect male end of Wiring Harness (LANEC300) to female end of Wiring Harness (LANEC100) installed in step 1 or original 31PIN connector factory installed on the header. Tighten plastic locking collar.
3. Position Multi-Coupler Block (LAN166990) in combine single point connector block. Secure and lock down handle.
4. Secure any loose parts of connected wiring harness to avoid damage during machine and transport.

Figure 1.1



Figure 1.2



For further technical information, contact Lankota: 866-526-5682