

LANGD400

Installation Instructions

Grain Divider Point for John Deere 600 Series 2016+ Flex & Draper Heads
and 2015 Draper Heads

LANKOTA[®]

270 West Park Avenue

Huron, SD 57350

877-860-7669

Numerical Parts List

<i>Part Numbers</i>	<i>Description</i>	<i>Quantity</i>
LANGD400	Grain Dividers Set of 2	1

Pictorial Parts List



Preparation

1. Lift head and place feeder house safety lock in the locked position

Procedure

Refer to Figure 1

1. Remove the metric screw from the front of the factory installed poly divider point and the two bolts from the bottom. Remove the plastic point.
2. Remove the two metric screws retaining the green metal plate.
3. Set a LANGD400 divider on the exposed snout point and replace all hardware and tighten.
4. Repeat on the other side.

For further technical questions, contact Lankota at 1-866-526-5682.



Figure 1