
LANCP22498 Installation Instructions

Lankota Weight Bracket Kit for JD® 12-16 Row 1770 & 1775 Corn Planters with Front Fold Markers

270 West Park Avenue Huron, SD 57350 866-526-5682

Numerical Parts List

Part Numbers	Description	Qty
LANWB22498A	Weight Bracket Left	1
LANWB22498AM	Weight Bracket Right	1



Preparation

- 1. Set corn planter to an appropriate working height at the ends of the wings.
- 2. Remove the markers and the marker mounting frames from both wings. Save the OEM break away bolt and hardware and the 1 1/2" pin if possible. If these parts are damaged upon removal, new parts will need to be purchased from your dealer.



Kit Installation

Refer to Figures 1 & 2

- 1. Using LANWB22498A on the left (driver side), pin to the planter using the original 1 1/2" diameter pin. Retain the bottom of the pin with the original snap ring.
- 2. Bolt the other side of the weight bracket with the original bolt and plate washer through the planter frame.



Figure 1

John Deere and JD are registered trademarks of Deere & Company. Lankota is a registered trademark of Lankota Group.

Figure 2

Kit Installation

Refer to Figures 3 & 4

- 3. Add up to 6 suitcase weights per bracket.
- 4. Bolt the weights together using the correct length hardware at the location shown below with a red arrow, to clamp the weights against the bottom center pin.

NOTE: Weight fastening hardware is not included.

Repeat steps on the opposite side of the planter.

For further technical assistance,

Call Lankota Inc. at:

1-866-526-5682






Figure 3

Figure 4

John Deere and JD are registered trademarks of Deere & Company. Lankota is a registered trademark of Lankota Group.